

#	LABEL	FUNCTION	COLOR	Ga.	ROUTING NOTES
1	Electric Cooling Fan	Switched Wire	GRAY	14	Not used
2	A/C Compressor	Switched Wire	Black	14	From A/C Control in Console to A/C Compressor Clutch
3	Cigarette Lighter Power	Constant Hot Wire	Tan	14	From Fuse Panel to Cigarette Lighter Socket in Console
4	A/C Heat Switch Power	Ignition Hot Wire	Black	14	From Fuse Panel to A/C Switch in Console
5	Wiper Switch Power	Ignition Hot Wire	Blue	16	From Fuse Panel to Washer Switch in Clock Housing
6	Electric Cooling Fan Switch Power	Ignition Hot Wire	Gray	14	Not used
7	Dimmer Switch	Constant Hot Wire	Blue	12	From Headlight Switch to Dimmer Switch
8	High Beam	Constant Hot Wire	Lt. Green	14	From Dimmer to Headlights
9	Low Beam	Constant Hot Wire	Tan	14	From Dimmer to Headlights
10	Right Door Lock	Constant Hot Wire	Yellow	14	
11	Right Power Window	Ignition Hot Wire	Yellow	12	
12	Left Door Lock	Constant Hot Wire	Yellow	14	
13	Left Power Window	Ignition Hot Wire	Yellow	12	
14	Alternator Exciter	Ignition Hot (not fused)	White	16	From Fuse Panel to Voltage Regulator
15					
16	Starter Battery Lug	Constant Hot Wire (50amp In Line fuse)	Red	10	From Battery connection on Starter Relay to Fuse Panel
17	Brake Switch Power	Constant Hot Wire	Orange	14	From Fuse Panel to Brake Switch
18	Brake Switch to Turn Switch	Switched Wire	White	14	Not used
19	Neutral Safety Switch	Switched Wire	Purple	12	From Ignition Switch Start Term to Neutral Safety Sw. Then on to Start Relay
20	- Side of Coil or HEI	Hot in Run and Start Position	Pink	14	
21	Temperature Sender	Sending Unit Wire	Green	18	From Gauge in Cluster to Sender
22	Oil Pressure Sender	Sending Unit Wire	Lt. Blue	18	From Gauge in Cluster to Sender
23	Tachometer	Sending Unit Wire	Purple	18	Not used
24	Horn	Constant Hot Wire	Green	14	
25	Front Right Turn Signal	Switched Wire	Blue	16	From Sequencer to Right Front Turn & Right Front Turn Indicator Bulb
26	Front Left Turn Signal	Switched Wire	Lt. Blue	16	From Sequencer to Left Front Turn & Left Front Turn Indicator Bulb
27	Front Parking Lights	Headlight Switch Power	brown	16	From Headlight Switch to Front Parking Lights
28	Headlight Switch Power	Constant Hot Wire	Red	12	From Fuse Panel to Headlight Switch
29	Tail Lights	Headlight Switch Power	Brown	14	From Headlight Switch to Tail Lights & Licence Plate Light
30	Power for Gauge Lights	Headlight Switch Power	Red	14	From Headlight Switch to Gauge Cluster Lights
31	Ignition Coil	Ignition Hot Wire	Pink	14	From Fuse Panel to HEI
32	Ignition Accessory	Ignition Hot (not Fused)	Brown	12	
33	Ignition Accessory	Ignition Hot (not Fused)	Orange	12	
34	Ignition Power	Constant Hot (not fused)	Red	12	From Fuse Panel to Ignition Switch Bat Terminal
35	Power for Gauges	Ignition Hot Wire	Red	16	
36	High Beam Indicator	Indicator	Green	18	From Dimmer Switch High Beam to High Beam Indicator Bulb in Cluster
37	Left Turn Indicator	Indicator	Lt. Blue	18	Not used
38	Right Turn Indicator	Indicator	Blue	18	Not used
39	Fuel Sending Unit	Sending Unit Wire	Pink	16	From Gauge in Cluster to Sender
40	Radio Constant	Constant Hot Wire	Red	18	From Fuse Panel to Radio Memory if After Market Radio is Used
41	Radio Ignition	Ignition Hot Wire	Red	18	From Fuse Panel to Radio Power
42	Power Antenna Signal	Switched Wire	Purple	18	From Radio to Antenna Signal if After Market Power Antenna is used
43	Power Antenna	Constant Hot Wire	Red	18	From Fuse Panel to Antenna Power if After Market Power Antenna is used
44					
45	Dome Light Power	Constant Hot Wire	White	16	From Fuse Panel to Courtesy Light Switches and Headlight Switch
46	Trunk Light Power	Constant Hot Wire	Green	16	From Fuse Panel to Trunk Light Switch & Bulb
47	Electric Fuel Pump Power	Ignition Hot Wire	Yellow	14	Not used
48	Right Rear Turn Signal	Switched Wire	Green	14	From Turn Signal Switch in Steering Column to Sequencer
49	Left Rear Turn Signal	Switched Wire	Yellow	14	From Turn Signal Switch in Steering Column to Sequencer
50					
51	Emergency Flasher	Constant Hot Wire	Brown	14	From Fuse Panel to EWS Switch in Overhead Console
52	Turn Signal Flasher	Ignition Hot Wire	Purple	14	From Fuse Panel to Turn Signal Switch in Steering Column
53	Relay Ground - Horn	Ground	Black	18	From Fuse Panel to Turn Signal Switch in Steering Column
54	Electric Choke	Ignition Hot Wire	Red	18	Not used
55	Third Brake Light	Switched Wire	Orange	18	From Brake Switch to Sequencer
56	Back-up Lights	Switched Wire	Green	18	From Backup Light Switch to Backup Light Bulbs
57	Cruise Control Power	Ignition Hot Wire	Pink	18	Not used
58	Back-up Lights Switch Power	Ignition Hot Wire	Green	18	From Fuse Panel to Backup Light Switch (with Starter Neutral Switch)
59					
60	Extra Constant Hot	Constant Hot Wire	Orange	14	
61	Extra Constant Hot	Constant Hot Wire	Blue	14	